

Windsor Plywood

IT'S WHAT'S UNDERNEATH THAT COUNTS!



QuietWalk
by QUICKSTYLE

THE ULTIMATE IN LAMINATE UNDERLAYMENT!

The new revolutionary Quiet Walk underlayment smooths out minor sub-floor imperfections while quieting impact sound and floor to ceiling noise. The protective covering resists moisture while our soft but firm pad adds cushion comfort under laminate or hardwood flooring.

Quiet Walk features:

- Reduces noise, but has a vapour barrier on one side of the pad for added moisture protection from concrete floors.
- Due to the high temperature process the underlayment is sanitized throughout.
- Kills all bacteria and fungus making it a good choice for allergy sufferers.

- Superior protection for laminate and floating wood floors
- Adds walking comfort and R-Value to chilly floors
- Suitable for use overall types of subfloors
- Holds up in today's hectic lifestyle
- Quality performance for many years to come

Installation Instructions

1. Be sure the subfloor is clean and dry
2. Roll Quietwalk™ underlayment over the subfloor with the vapor barrier film (logo imprinted side) facing up to allow the laminate floor to slide easily over the surface.
3. The perimeter edges of Quiet Walk™ need to be 1/2 to 3/4 inches away from the wall
4. Seams need to be butted together flush, do not overlap the pad. Tape the seams with water and tear resistant, utility-grade, poly-coated cloth backed tape that has a very aggressive adhesive (duct tape).
5. Install laminate flooring according to the manufacturer's installation instructions.

QuietWalk
by QUICKSTYLE



ABSORBS SOUND

COME IN TODAY AND SEE THE DIFFERENCE!

The *experts* you
need to know!

Windsor Plywood